

Manually add Internet radio stations

This chapter explains how to register with Philips and add individual URL addresses for Internet radio stations on the PC. The easiest way to register is to visit www.philips.com/welcome and follow the on-screen instructions to register NP2500. Alternatively, you have the option to register NP2500 on the device:

- 1 Ensure that NP2500 is turned on.
- 2 Ensure that NP2500 is connected to the Internet.
- 3 On NP2500, select **[Settings]** > **[Register now]** > **[Register on the device]**.
↳ The registration display is shown.
- 4 Press alphanumeric buttons on the remote control to enter your valid email address.
- 5 Press **OK**.
↳ The display confirms the automated email dispatch to your mailbox.
- 6 Check the email inbox for a message from **ConsumerCare@Philips.com** with the subject **Your Streamium Registration....**
- 7 Follow the instructions in the email to complete your registration process on the Philips website.
- 8 On the registered product site, click the link **Streamium Management**.
- 9 Select **My Media**.
- 10 Click on the tab **Music**.
- 11 Enter the URL address of Internet radio station in the first column.
- 12 Enter a nickname in the second column.
↳ The nickname is the Internet radio stations identification that is displayed
- 13 Enter a description in the third column.
- 14 Click on **Save** to confirm your entries.

Note

- If the manually added Internet radio station is available and broadcast in a compatible format, you can listen to it on NP2500.
- You can find the manually added Internet radio stations in the My Media list on NP2500.
- Internet radio features require broadband Internet access.

Listen to My Media

When you manually add an Internet radio station, the Internet radio station is found under **[My Media]**.

- 1 Turn on NP2500.
- 2 Ensure that NP2500 is connected to broadband Internet.
- 3 Press **INTERNET RADIO**.
- 4 Select **[My Media]**.
↳ The display shows the list of Internet radio stations stored under **[My Media]**.
- 5 Press **OK** to start play.
 - To return to the Home menu, press **HOME**.

Note

- The feature **My Media** requires registration with **Club Philips**.
- Internet radio features require broadband Internet access.